

PSD Codax Ltd

Axis 8 Hawkfield Business Park
 Whitchurch Bristol BS14 0BJ
 United Kingdom
www.psdcodax.com



Codax Embedded Terminal (CET-SER)

Quick Start Guide

This Quick Start Guide outlines the minimum initial steps required to get the Codax Embedded Terminal configured and ready to issue tickets. This guide should be used in conjunction with the user manual for Codax Embedded Terminal – CET-SER-UM-ENG-280121-1.05.

Step 1 Cold Start

SYSTEM NOT CONFIGURED
COLD START REQUIRED



→ Admin Menu → Command → Password 32923

Cold Start is the process used to configure the Ticket Terminal to match the physical site installation in terms of services and programs available. See *CET user manual section 4.3 - COLD START*

Step 2 System Setup

PSD Codax
12:56



→ Admin Menu → Setup → Password 12345

The System Setup is defined by a series of setup options available from the Setup menu. These setup options fully customise the Ticket Terminal's operation and ticket details. The list below shows the minimum setup requirement. See *CET user manual section – 4.5 – SET-UP MENU FUNCTIONS:*

- Set Time and Date – *Section 4.5.1 - TIME AND DATE*
- Set Ticket Validity – *Section 4.5.2 - VALIDITY*
- Serial Port Setup – *Section 4.5.5 – SERIAL PORT SETUP*
- Test Comms Link – *Section 4.5.8 – COMMS LINK TEST*

Step 3 Issue Wash Tickets

PSD Codax
12:56

Tickets are only available using the appropriate Serial Protocol.

Contact PSD Codax for relevant documentation for the Serial Protocol set for your terminal.

Refer to the Codax Embedded Terminal Operators Manual for further features and options.